



TECHNICAL DATA SHEET

LANDORA OUTDOOR WOODSTAIN

Landora Outdoor Woodstain protects and penetrates into the surface and is suitable for outdoor wood flooring, garden furniture and other outdoor woodwork. The product is suitable for most surfaces, such as pine and pressure treated wood. The product protects the wood against harmful UV radiation.

NB! Landora Outdoor Woodstain cannot be used as a primer. Apply the product when the weather is suitable. It must be dry and not too hot.

Environmental considerations: Surplus product is not to be disposed of in common drains. This material and its container must be disposed of properly.

Directions for use

Stir well before use and frequently during application.

1. Make sure the surface is solid, free from loose material and without any damaged wood.
2. Clean the surface using Landora Outdoor Wood Cleaner and let the surface dry thoroughly.
3. Apply 1 coat of Landora Outdoor Woodstain. Apply along each plank, 1 or 2 at a time. Do not apply more than the wood will soak up, there should not be a film on the surface.
4. Wait a few minutes, then wipe off any excess using a piece of cloth or a sponge.
5. Repeat the treatment when the surface is fully dry, if needed.

The master painter suggests: Apply the product only when the surface is dry and firm. Wipe off any excess with a cloth in order to prevent a film from forming.

Technical data:

Consumption: approx. 6-10 m²/litre, depending on the state of the surface.

Drying time at 20°C: approx. 20 hours.

Application: Brush or cloth.

Cleaning of tools: Landora Brush Cleaner or soap and water.

TO BE STORED AWAY FROM FROST

KEEP OUT OF REACH OF CHILDREN

The product is available in the following amounts:

2.5 litre: Brown



Produced for the Landora brand.

Manufacturer: Hagmans Nordic AB, SE-511 10 Fritsla, Sweden.

Contact: +46-320-189 00, landora.com