

## **TECHNICAL DATA SHEET**

## LANDORA WOOD DECK CLEANER

Landora Wood Deck Cleaner is an effective alkaline detergent for outdoor cleaning of stone, concrete and wood decks. It will remove residues from dirt, algae, mold and old wood oil.

Do not use it on hardwood since it may become discoloured (e.g. teak).

**Environmental considerations:** Surplus liquid is not to be disposed of in common drains. Any surplus liquid and the container is to be handed in to your local recycling station.

## **Directions for use**

- **1.** Protect windows, glass sections and other items that may be damaged by alkaline products, such as aluminium. Also protect the garden vegetation.
- 2. Flush the surface with water.
- **3.** Apply Landora Wood Deck Cleaner with a brush or spray gun. Let the product soak on the surface for approx.10 minutes and then wash off with water and a stiff brush.
- **4.** Rinse thoroughly with water. If you intend to apply wood oil after the treatment, any residue may have negative effect unless it is totally removed.

Repeat the procedure on heavily affected surfaces.

**The paint master says:** Do not use it on hardwood since it may become discoloured. Remember to protect the garden plants.

## **Technical data**

Application: Brush or spray gun.

The product is available in the following amounts:

1.0 litre

2.5 litre

